

Make Life Easy 

User Manual

Displacement Sensor

BD Series

MSO-BDU1-V1.1-2002US

Thank you for purchasing an Autonics product.

This user manual contains information about the product and its proper use,
and should be kept in a place where it will be easy to access.

www.autonics.com

Autonics

Preface

Thank you for purchasing Autonics product.

Please familiarize yourself with the information contained in the **Safety Considerations** section before using this product.

This user manual contains information about the product and its proper use, and should be kept in a place where it will be easy to access.

User Manual Guide

- Please familiarize yourself with the information in this manual before using the product.
- This manual provides detailed information on the product's features. It does not offer any guarantee concerning matters beyond the scope of this manual.
- This manual may not be edited or reproduced in either part or whole without permission.
- This manual is not provided as part of the product package. Please visit our website (www.autonics.com) to download a copy.
- The manual's content may vary depending on changes to the product's software and other unforeseen developments within Autonics, and is subject to change without prior notice. Upgrade notice is provided through our homepage.
- We contrived to describe this manual more easily and correctly. However, if there are any corrections or questions, please notify us these on our website.

User Manual Symbols

| Symbol | Description |
|--|--|
|  Note | Supplementary information for a particular feature. |
|  Warning | Failure to follow instructions can result in serious injury or death. |
|  Caution | Failure to follow instructions can lead to a minor injury or product damage. |
|  Ex. | An example of the concerned feature's use. |
| ※ | Annotation mark. |

Safety Considerations

- Following these safety considerations will ensure the safe and proper use of the product and help prevent accidents, as well as minimizing possible hazards.
- Safety considerations are categorized as Warnings and Cautions, as defined below:

| | | |
|--|----------------|--|
|  Warning | Warning | Failure to follow the instructions may lead to a serious injury or accident. |
|--|----------------|--|

| | | |
|--|----------------|--|
|  Caution | Caution | Failure to follow the instructions may lead to a minor injury or accident. |
|--|----------------|--|



Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
Failure to follow this instruction may result in personal injury, economic loss or fire.
- Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
Failure to follow this instruction may result in explosion or fire.
- Do not disassemble or modify the unit.
Failure to follow this instruction may result in fire.
- Do not connect, repair, or inspect the unit while connected to a power source.
Failure to follow this instruction may result in fire.
- Check 'Connections' before wiring. [Amplifier unit]
Failure to follow this instruction may result in fire.



Caution

- Do not stare at the laser emitter. [Sensor head]
Failure to follow this instruction may result in eye damage.
- Use the unit within the rated specifications.
Failure to follow this instruction may result in fire or product damage.
- Use dry cloth to clean the unit, and do not use water or organic solvent.
Failure to follow this instruction may result in fire.
- Mount the ferrite core to specified position before using. [Sensor head, Extension cable]
Failure to follow this instruction may result in output with noise.

Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- The power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- Do not install where strong magnetic or electric field exist. Otherwise, the resolution may be adversely affected.
- Mutual optical interference between laser sensors and photoelectric sensors may result in malfunction.
- Mutual optical interference between laser sensors may result in malfunction.
- When connecting DC relay or other inductive load to the output, remove surge by using diode or varistor.
- Wire as short as possible and keep away from high voltage lines or power lines, to prevent surge and inductive noise. [Amplifier unit]
- For the optimized performance, it is recommended to measure after 30 minute from supplying power. [Amplifier unit]
- Since external disturbance light (sunlight, fluorescent lighting, etc.) can cause product malfunction, use the product with a light shield or slit. [Sensor head]
- When detecting with the maximum sensitivity, an error may occur depending on each characteristic deviation.
- This unit may be used in the following environments.
 - ① Indoors/Outdoors (in the environment condition rated in 'Specifications')
 - ② Altitude max. 2,000m
 - ③ Pollution degree 2
 - ④ Installation category II

The specifications are subject to change and some models may be discontinued without notice.

Be sure to follow cautions written in the instruction manual, user manual and the technical descriptions (catalog, website).

Table of Contents

| | |
|--|-----------|
| 1 Overview | 12 |
| 1.1 Features..... | 12 |
| 1.1.1 Sensor head/Amplifier unit | 12 |
| 1.1.2 Communication converter | 12 |
| 1.2 Warning Label..... | 13 |
| 1.2.1 Label description..... | 13 |
| 1.2.2 Label attachment locations..... | 14 |
| 1.3 Components and Sold separately..... | 15 |
| 1.3.1 Sensor head..... | 15 |
| 1.3.2 Amplifier unit..... | 16 |
| 1.3.3 Communication converter | 17 |
| 1.4 Product configuration | 19 |
| 1.5 Model configuration | 19 |
| 1.5.1 Sensor head..... | 19 |
| 1.5.2 Amplifier unit..... | 20 |
| 1.5.3 Communication converter | 20 |
| 1.5.4 External cable..... | 20 |
| 1.6 Unit Description..... | 21 |
| 1.6.1 Sensor head..... | 21 |
| 1.6.2 Amplifier unit..... | 22 |
| 1.6.3 Communication converter | 23 |
| 2 Specification | 24 |
| 2.1 Sensor Head | 24 |
| 2.2 Amplifier Unit | 26 |
| 2.3 Communication Converter..... | 28 |
| 3 Product Connection | 29 |
| 3.1 Amplifier Unit | 29 |
| 3.1.1 Connection..... | 29 |
| 3.1.2 Control output diagram | 29 |
| 3.2 Communication Converter..... | 30 |
| 3.2.1 Connection..... | 30 |

| | | |
|----------|--|-----------|
| 4 | Dimension | 31 |
| 4.1 | Sensor Head | 31 |
| 4.1.1 | Bracket (accessory) | 31 |
| 4.1.2 | Ferrite core (accessory) | 31 |
| 4.1.3 | Extension cable (sold separately)..... | 31 |
| 4.2 | Amplifier Unit | 32 |
| 4.2.1 | Bracket (accessory) | 32 |
| 4.2.2 | Extension cable (sold separately)..... | 32 |
| 4.3 | Communication Converter..... | 33 |
| 5 | Installation | 34 |
| 5.1 | Installation Procedures | 34 |
| 5.2 | Sensor Head | 35 |
| 5.2.1 | Mounting..... | 35 |
| 5.2.2 | Mounting Location | 35 |
| 5.2.3 | Installation Precautions | 37 |
| 5.3 | Amplifier Unit | 39 |
| 5.3.1 | Mounting with bolt..... | 39 |
| 5.3.2 | Mounting on DIN rail..... | 39 |
| 5.4 | Check Point for Installing Sensor Head and Amplifier Unit..... | 40 |
| 5.4.1 | Ferrite core (accessory) | 40 |
| 5.4.2 | Connecting to amplifier unit | 40 |
| 5.4.3 | Connecting amplifier units mutually..... | 41 |
| 5.4.4 | Distinguishing master/slave amplifier units..... | 41 |
| 5.4.5 | Precautions when connecting amplifier unit..... | 41 |
| 5.5 | Communication Converter..... | 42 |
| 5.5.1 | Mounting on DIN rail..... | 42 |
| 5.6 | Check Point for Installing Communication Converter | 43 |
| 5.6.1 | Connecting to amplifier unit | 43 |
| 5.6.2 | Distinguishing master/slave amplifier units..... | 43 |
| 5.6.3 | Precautions when connecting amplifier unit..... | 44 |
| 6 | Function – Amplifier Unit | 45 |
| 6.1 | Display When Power is ON..... | 45 |
| 6.2 | Mode Setting..... | 46 |
| 6.2.1 | Parameter setting..... | 46 |

| | | |
|----------|--|-----------|
| 6.2.2 | RUN mode setting | 47 |
| 6.2.3 | Sensing optimization..... | 48 |
| 6.2.4 | Zero adjustment..... | 48 |
| 6.2.5 | Sensitivity adjustment | 49 |
| 6.2.6 | Control output type..... | 51 |
| 7 | Parameter Group – Amplifier unit | 52 |
| 7.1 | Setting..... | 52 |
| 7.2 | Configuration, Setting range and Factory default | 52 |
| 7.3 | Parameter Group 1 [PARAM1] | 57 |
| 7.3.1 | Response time [RESPd]..... | 57 |
| 7.3.2 | Teaching mode [SENS]..... | 57 |
| 7.3.3 | Output type [NONE] | 58 |
| 7.3.4 | PV display [DISP] | 58 |
| 7.3.5 | Display digit [DIGIT] | 58 |
| 7.3.6 | Display scale [H-SC / L-SC]..... | 58 |
| 7.3.7 | Hysteresis [HYS] | 60 |
| 7.3.8 | Analog output scale [H-AN / L-AN]..... | 60 |
| 7.3.9 | Error output [ERR.OUT] | 61 |
| 7.3.10 | Fixed output [FIX.OUT] | 62 |
| 7.4 | Parameter Group 2 [PARAM2] | 63 |
| 7.4.1 | Calculation [CALC] | 63 |
| 7.4.2 | Gain [GAIN] | 65 |
| 7.4.3 | Filter [FILTER]..... | 65 |
| 7.4.4 | Samples for averaging [AVF]..... | 66 |
| 7.4.5 | Samples for median [MEDIAN]..... | 66 |
| 7.4.6 | Hold [HOLD]..... | 66 |
| 7.4.7 | Hold timing input [HOLDt] | 69 |
| 7.4.8 | Auto trigger level [ATLV]..... | 70 |
| 7.4.9 | Auto trigger hysteresis [ATHYS]..... | 70 |
| 7.4.10 | Timer [t-MODE]..... | 70 |
| 7.4.11 | Timer value [tME]..... | 71 |
| 7.5 | Parameter Group 3 [PARAM3] | 72 |
| 7.5.1 | External input <input type="checkbox"/> [d-IN <input type="checkbox"/>] | 72 |
| 7.6 | Parameter Group 4 [PARAM4] | 75 |
| 7.6.1 | Display direction [DIR]..... | 75 |

| | | |
|----------|---|-----------|
| 7.6.2 | Bank [bANK] | 75 |
| 7.6.3 | Saving mode [SAVE]..... | 76 |
| 7.6.4 | Lock mode [LOCK]..... | 76 |
| 7.6.5 | Initialize [INIT]..... | 77 |
| 8 | Error – Amplifier unit..... | 78 |
| 9 | Communication Converter | 80 |
| 9.1 | Communication Setting Switch | 80 |
| 9.2 | Status Indicator – Communication converter..... | 82 |
| 9.3 | Dedicated Device Management Program (atDisplacement)..... | 83 |

1 Overview

1.1 Features

Displacement sensor BD Series can accurately measure displacement precisely by high resolution (max. 1 μ m, BD-030) and wide measurement range (max. 120mm, BD-100).

And consists of a connector type sensor head, an amplifier unit which can be connected up to 8 units, and a communication converter which supports RS-232C, RS-485 communication, to configure the measuring system efficiently.

1.1.1 Sensor head/Amplifier unit

- Easy maintenance with separable structure of sensor head/amplifier unit
- Maximum resolution: 1 μ m (different by models)
- Stable measurement regardless of color or material of the object
- Mutual connection up to 8 amplifier units
: Interference prevention and channel alignment are automatically applied
- Various calculation function (add, subtraction, average)
- Various filter function for stable measurement (average, differential, median)
- Teaching modes configuration (1-point, 2-point) for user environment
- Mounting on DIN-Rail or wall (accessory bracket is needed) is available
- Sensor head IP67 protection structure (patented)
: Korea patent application number 2017-0043925

1.1.2 Communication converter

- Supports RS232C and RS485 communications in one device
: Separated ports of RS232C/RS485 for user convenience
- Maximum connection up to 8 amplifier units
- Power supply without extra wiring via amplifier unit
- Dedicated Device Management Program (atDisplacement)
: Batch parameter setting via save/load function
: Real-time monitoring of measured values and output status
- Communication speed and station number can be set by side DIP switch without connecting host device

1.2 Warning Label


The description on the warning labels attached to the device and the label locations are described below.

1.2.1 Label description

- BD-030



- BD-065




- BD-100




1.2.2 Label attachment locations


- BD-030



- BD-065



- BD-100




1.3 Components and Sold separately

1.3.1 Sensor head


(1) Components



- BD series sensor head




- Bracket for sensor head



- Ferrite core
- Bolt, Nut 2 sets
- Instruction manual


(2) Sold separately




- External cable for sensor head and amplifier unit

1.3.2 Amplifier unit


(1) Components



- BD series amplifier unit




- Bracket for amplifier unit



- Side connector

- Instruction manual



(2) Sold separately




- External cable for sensor head and amplifier unit

1.3.3 Communication converter

(1) Components




- BD-C series communication converter - Side connector




- RS485 connector
- Instruction manual


(2) Sold separately



- SCM-WF48 (Wi-Fi, USB - RS485)



- SCM-US48I (USB - RS485)




- SCM-38I (RS232C - RS485)



Note

- Please make sure that all of the components are included before using the product. If either component is damaged or missing, please contact our sales office.
- Components and sold separately image may be slightly different.

1.4 Product configuration



1.5 Model configuration

1.5.1 Sensor head

| Model | Beam shape | Reference distance (Maximum measurement range) | Spot diameter | | |
|--------|------------|---|------------------------------------|-------------------------------------|------------------------------------|
| | | | Near | Reference | Far |
| BD-030 | Standard | 30mm (20-40mm) | Apporx. 290×790μm (at 25mm) | Apporx. 240×660μm (at 30mm) | Apporx. 190×450μm (at 35mm) |
| BD-065 | Standard | 65mm (50-80mm) | Apporx. 360×1590μm (at 55mm) | Apporx. 290×1180μm (at 65mm) | Apporx. 210×830μm (at 75mm) |
| BD-100 | Standard | 100mm (70-130mm) | Apporx. 480×1870μm (at 80mm) | Apporx. 410×1330μm (at 100mm) | Apporx. 330×950μm (at 120mm) |

1.5.2 Amplifier unit

| Model | Compatible sensor head |
|-------|--------------------------|
| BD-A1 | BD series sensor head: 1 |

1.5.3 Communication converter


| Model | Supported communication function |
|--------|----------------------------------|
| BD-CRS | RS-232C, RS-485 |

1.5.4 External cable

| Model | Cable length |
|----------------|--------------|
| CID6P-1-SI-BD | 1m |
| CID6P-2-SI-BD | 2m |
| CID6P-5-SI-BD | 5m |
| CID6P-10-SI-BD | 10m |

1.6 Unit Description

1.6.1 Sensor head



1. Power indicator (red)

Indicates whether power supply the sensor head.

2. Receiver

Receives reflected laser from the object.

3. Emitter

Emits laser to the object to measure the displacement.

4. Emission center line

The line and the object should be aligned because the laser is emitted along the line.

5. Laser emission indicator (green)

Lights ON during sensor head emits laser.


6. NEAR/FAR indicator (green)

- Out of the rated measurement range: Flashing
- Near the reference distance: Turns on
- ※ For the details, refer to '5.2.2 Mounting Location - Indicator display'.

7. Mounting hole

8. Connector cable

1.6.2 Amplifier unit



1. Present value (PV) display

Displays PV, calculating result (when using calculation), parameter name (when setting parameter).

2. Setting value (SV) display

Displays SV (HIGH, LOW, RV, Analog output, Bank), parameter setting value (when setting parameter). The type of displaying SV can be recognized by 'Setting value (SV) indicator recognition'.

3. Judgment indicator (Red: HI / LO, Green: GO)

Lights ON when outputting judgment value following to SV.

4. Alarm indicator (Red)

Lights ON when outputting alarm.

5. Optimization setting key [AUTO]

Executes 'Sensing optimization'.

6. Setting value (SV) indicator recognition lamp (Green)

Displays the value type of 'Setting value (SV) display'

- HI/LOW: HIGH/LOW judgment value
- RV: Real distance value
- ANALOG: Analog output

7. Zero adjustment setting key [ZERO]

Executes 'Zero adjustment'.

8. Mode setting key [MODE]

Enters modes and sets the parameter value.

9. Direction key [◀] / [▶] / [▲] / [▼]

Sets the value of mode and parameter.

10. Calculation indicator (CALC, Green)

Lights ON when using calculation.


11. Measurement range indicator (RANGE, Green)

Lights ON when PV is in the measurement range, lights OFF when PV is out of the measurement range or emitting laser is stopped.

12. Laser emission indicator (LASER, Green)

Lights ON when emitting laser.

1.6.3 Communication converter



1. RS485 terminating switch

Set the switch to 'RT' when the communication converter is connected to the terminal of RS485 communication connection.

2. RS232C connector

A connector for RS232C communication.

3. Status indicator

Displays power, communication input/output/error.

- Power indicator (POWER, Green): Displays power supply.
- Communication output indicator (TX, Green): Displays communication output status from communication converter to external device.
- Communication input indicator (RX, Green): Displays communication input status from communication converter to external device.
- Communication error indicator (ERROR, Red): Displays the communication status of communication converter.

4. Communication Setting Switch

Sets communication speed, address, parity bit and stop bit.

5. RS485 connector

A connector for RS485 communication.

6. Side connector

A connector for connecting between communication converter and amplifier unit.

2 Specification

2.1 Sensor Head

| Model | BD-030 | | | BD-065 | | | BD-100 | | | |
|---|---|--|------------------------|------------------------------|---|------------------------|--------------------------------|-------------------------|------------------------|--|
| Spot diameter (Unit: μm) | Near (25mm) | Reference (30mm) | Far (35mm) | Near (55mm) | Reference (65mm) | Far (75mm) | Near (80mm) | Reference (100mm) | Far (120mm) | |
| | Approx. 290× 790 | Approx. 240× 660 | Approx. 190× 450 | Approx. 360× 1590 | Approx. 290× 1180 | Approx. 210× 830 | Approx. 480× 1870 | Approx. 410× 1330 | Approx. 330× 950 | |
| Resolution ^{*1} | 1 μm | | | 2 μm | | | 4 μm | | | |
| Reference distance | 30mm | | | 65mm | | | 100mm | | | |
| Maximum measurement range | 20 to 40mm | | | 50 to 80mm | | | 70 to 130mm | | | |
| Linearity ^{*1*2} | 0.1% F.S. (in 25 to 35mm) | | | 0.1% F.S. (in 55 to 75mm) | | | 0.15% F.S. (in 80 to 120mm) | | | |
| Temperature Characteristics ^{*3} | 0.05% F.S. | | | 0.06% F.S. | | | | | | |
| Power supply ^{*4} | - | | | | | | | | | |
| Light Source | Red semiconductor laser (wavelength: 660nm, IEC 60825-1:2014) | | | | | | | | | |
| | Optical method | Diffuse reflection | | | | | | | | |
| | Laser class | Class 1 (IEC/EN), Class I (FDA(CDRH) CFR Part 1002) | | | Class 2 (IEC/EN), Class II (FDA(CDRH) CFR Part 1002) | | | | | |
| | Output | Max. 300 μW | | | Max. 1mW | | | | | |
| Operation indicators | Power indicator: red LED, Laser emission indicator: green LED, NEAR/FAR indicator: green LED | | | | | | | | | |
| Connection | Connector type | | | | | | | | | |
| Insulation resistance | Over 20M Ω (at 500VDC= megger) | | | | | | | | | |
| Noise immunity | Square shaped noise by noise simulator (pulse width: 1 μs) \pm 500V | | | | | | | | | |
| Dielectric strength | 1,000VAC 50/60Hz for 1 minute | | | | | | | | | |
| Vibration | 1.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 2 hours | | | | | | | | | |

| | | | |
|------------------------------|---|-----------------------------------|-------------------------------|
| Shock | 300m/s ² (Approx. 30G) in each X, Y, Z direction for 3 times | | |
| Environment | Ambient Illumination | Max. incandescent lamp 10,000lx | |
| | Ambient temperature | -10 to 50°C, Storage: -15 to 60°C | |
| | Ambient humidity | Under 85%RH, Storage: Under 85%RH | |
| Protection structure | IP67 (IEC Standards, except connector of extension cable) | | |
| Material | Case: Polycarbonate, Sensing part: Glass, Cable: Polyvinyl chloride | | |
| Amplifier unit compatibility | BD Series amplifier unit: 1 | | |
| Accessory | Ferrite core (made by TDK co. ZCAT2132-1130), Mounting bracket, Bolt, Nut | | |
| Approval |  | | |
| Weight ^{※5} | Approx. 209g (approx. 56g) | Approx. 233g (approx. 68g) | Approx. 233g (approx. 68g) |

- ※1: When measuring fixed non-glossy white paper (reference temperature: 25°C, reference distance, response time: 1ms, average 128 times).
- ※2: Value indicates the error with respect to the ideal straight line and the numbers in parentheses are the rated measurement ranges guarantee linearity.
- ※3: Value measured by using an aluminum jig fix the sensor head and non-glossy white paper.
- ※4: Using power from the amplifier unit.
- ※5: The weight is with packaging and the weight in parenthesis is only unit weight.
- ※ The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

2.2 Amplifier Unit

| Model | | BD-A1 |
|-------------------------------|---------------------|--|
| Power supply | | 10-30VDC \pm 10% (When connecting BD-C Series communication converter, 12-30VDC \pm) |
| Power consumption | | Max. 2800mW (30VDC \pm , except connected) |
| Control input \ast 1 | Timing | No-voltage input |
| | Output reset | |
| | Laser OFF | |
| | Zero adjustment | |
| | Bank change | |
| Judgment output (HIGH/GO/LOW) | | NPN or PNP open collector output (Load current: Max. 100mA) |
| Alarm output | | NPN or PNP open collector output (Load current: Max. 100mA) |
| Analog output \ast 2 | Voltage | -5-5V, 0-5V, 1-5V (Resistance: 100 Ω , \pm 0.05% F.S., at 10V) |
| | Current | 4-20mA (Max load resistance: 350 Ω , \pm 0.2% F.S., at 16mA) |
| Residual voltage | | NPN: Max. 1.5V, PNP: Max. 2.5V |
| Protection circuit | | Reverse polarity protection circuit, output overcurrent (short-circuit) protection circuit |
| Response time | | 0.33, 0.5, 1, 2, 5ms (5-step adjustment) |
| Min. display unit | | 1 μ m |
| Display method | | Dual display by 6-digit, 11-segment LED |
| Display range \ast 3 | | \pm 99.999mm to \pm 99mm (4-step adjustment) |
| Display period | | Approx. 100ms |
| Insulation resistance | | Over 20M Ω (at 500VDC \pm megger) |
| Noise immunity | | Square shaped noise by noise simulator (pulse width: 1 μ s) \pm 500V |
| Dielectric strength | | 1,000VAC 50/60Hz for 1 minute |
| Vibration | | 1.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 2 hours |
| Shock | | 300m/s ² (Approx. 30G) in each X, Y, Z direction for 3 times |
| Environment | Ambient temperature | -10 to 50°C, storage: -15 to 60°C |
| | Ambient humidity | Under 85%RH, Storage: Under 85%RH |
| Protection structure | | IP40 (IEC Standards) |
| Material | | Case: Polycarbonate, Cover: Polycarbonate, Cable: Polyvinyl chloride |
| Connection | | Connector type |

| | |
|---------------------------|---|
| Sensor head compatibility | BD Series sensor head: 1 |
| Accessory | Mounting bracket, Side connector |
| Approval | CE c  US |
| Weight ^{※4} | Approx. 228g (approx. 126g) |

※1: Use after assigning to external input line.

※2: It is possible to use among -5-5V, 0-5V, 1-5V, 4-20mA by parameter setting.

※3: Setting range is assigned automatically when connecting sensor head.

※4: The weight is with packaging and the weight in parenthesis is only unit weight.

※ The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

2.3 Communication Converter

| Model | | BD-CRS |
|----------------------------|---------------------|---|
| Power supply ^{※1} | | - |
| Power consumption | | Max. 2.3W |
| Communication function | | RS-232C, RS-485 |
| Communication speed | | 9600, 19200, 38400, 115200bps (default) |
| Indication | | 4 LED status indicators |
| Function | | <ul style="list-style-type: none"> • Real-time monitoring • Executes every BD-Series feature and sets parameter by external device (Master) |
| Environ-ment | Ambient temperature | -10 to 50°C, Storage: -15 to 60°C |
| | Ambient humidity | 35 to 85%RH, Storage: 35 to 85%RH |
| Vibration | | 1.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 2 hours |
| Shock | | 300m/s ² (approx. 50G) in each X, Y, Z direction for 3 times |
| Protection structure | | IP40 (IEC Standards) |
| Material | | Case: Polycarbonate |
| Accessory | | Side connector, Connector for RS485 |
| Sold separately | | Communication converter (SCM-38I, SCM-US48I, SCM-WF48) |
| Approval | |  |
| Weight ^{※2} | | Approx. 91g (approx. 49g) |

※1: Using power from the amplifier unit. To use BD-C Series communication converter, the amplifier unit needs 12-30VDC power supply.


※2: The weight is with packaging and the weight in parenthesis is only unit weight.

※ The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

3 Product Connection

3.1 Amplifier Unit


3.1.1 Connection




| Item | Code color | Description |
|--------|----------------|--|
| Power | Brown | Power: 10-30VDC |
| | Blue | Common GND (input, output, power) |
| Output | Black | HIGH Judgment |
| | Orange | LOW Judgment |
| | Gray | GO Judgment |
| | Green | Alarm |
| | White | Analog: Following parameter value (-5-5V, 0-5V, 1-5V, 4-20mA) |
| | Shield | GND (Analog output) ※It is needed to distinguish from common GND. |
| | External input | Pink |
| Yellow | | External input 2 |
| Red | | External input 3 |
| Purple | | External input 4 |

3.1.2 Control output diagram

- Judgment (High, Go, Low) and alarm output




- Analog output (-5-5V, 0-5V, 1-5V, 4-20mA)



3.2 Communication Converter


3.2.1 Connection

(1) RS232C communication




(2) RS485 communication

- Application of system organization




- Terminating switch



Set the switch to 'RT' when the communication converter is connected to the terminal of RS485 communication connection, and set to 'OFF' when it is in the middle of the communication connection.

- Communication pin




| Pin | Name | Description |
|-----|------|----------------|
| 1 | A(+) | RS485 + Signal |
| 2 | B(-) | RS485 - Signal |


4 Dimension

(unit: mm)


4.1 Sensor Head




4.1.1 Bracket (accessory)



4.1.2 Ferrite core (accessory)




4.1.3 Extension cable (sold separately)




4.2 Amplifier Unit

(unit: mm)



4.2.1 Bracket (accessory)




4.2.2 Extension cable (sold separately)



4.3 Communication Converter

(unit: mm)




5 Installation

5.1 Installation Procedures

| Order | Chapter | Description |
|-------|---|---|
| 1 | Check reference distance and | As the distance between the sensor head and the object approaches the reference distance, accurate measurements can be made. Refer to '5.2.2 Mounting Location'. |
| 2 | Select mounting location | In case of measuring moving or rotating object, it is needed to install the sensor head to correct direction. When measuring at narrow area or concave object, it is needed to set the position of the sensor head. For the details, refer to '5.2.3 Installation Precautions'. |
| 3 | Check the precautions about the measurement | Mount to the panel directly or through the enclosed bracket. Refer to '5.2.1 Mounting' to mount the sensor head. |
| 4 | Check mounting method and mount | BD series support various settings and functions such as pitch light optimization, zero adjustment setting, automatic sensitivity setting, calculation through the amplifier unit. Refer to '5 Installation - 5.3 Amplifier Unit', '6 Function - Amplifier Unit'. |
| 5 | Check and apply the function of communication converter | It is possible to set parameters, monitor and manage data by connecting between communicate between BD-C Series communication converter and master device. Refer to '5 Installation - 5.5 Communication Converter'. |

5.2 Sensor Head

5.2.1 Mounting



- Check the mounting position considering emission center line, vibration and shock.
- Mount to the panel directly or through the bracket by using M3 bolt and nut.
- Tighten the bolt with 0.5N.m torque when mounting.


5.2.2 Mounting Location

Select mounting location regarding displacement of the object, reference distance and measurement range.

Mount sensor head where the object is located at the reference distance by checking the operation of indicators and displacement value.

- **Indicator display**


Check the distance between sensor head and object by indicator display.



- NEAR/FAR indicators turn on, off and cross-flashing by the distance between the sensor head and the object and the indicator are on both, it means the sensor head is located in optimum area near reference distance.
- Power indicator is on when power is supplied.
- Laser emission indicator is on during laser emission.

※ The linearity guaranteed measurement range.

▪ Displacement indication



The value is displaced more positive (+) as the object is closer to sensor head, more negative value (-) as the object is far from sensor head relative to the origin (0).

▪ Indication by distance

(unit: mm)


| Model | Reference Distance | Rated measurement range* | Indication | | |
|--------|--------------------|--------------------------|------------|-------------|-----------|
| | | | NEAR ON | NEAR/FAR ON | FAR ON |
| BD-030 | 30 | 25 to 35 | 25 to 31 | 29 to 31 | 29 to 35 |
| BD-065 | 65 | 55 to 75 | 55 to 67 | 63 to 67 | 63 to 75 |
| BD-100 | 100 | 80 to 120 | 80 to 104 | 96 to 104 | 96 to 120 |

※ The linearity guaranteed measurement range.

5.2.3 Installation Precautions


For stable measurement, mount the sensor head by referring to the below items.

- **Moving object measurement**
 - Object with material / color difference




Install the emitter and receiver in parallel to the material or color boundary of the object.

- Rotating object




Install the receiver and the rotating shaft in parallel to minimize the influence of fluctuations and position deviations.

- Object with step




Install the emitter and receiver vertically to the line between crest and valley of the object.

- **Narrow area or concave object**



Install the sensor head where the reflected laser beam does not blocked toward the receiver part.


- **Wall mounting**



Install the sensor head where the reflected laser beam from the wall does not enter the receiver part.

If the color of wall is black with low reflectivity and no gloss, the error can be minimized.

- **Black object**



When measuring black object with low reflectance the amount of light received decreases, install the sensor head closely to the object.


5.3 Amplifier Unit

5.3.1 Mounting with bolt

- Mounting without DIN rail is possible by using bracket.
- The method of mounting and detaching with bracket is as same as DIN rail.


5.3.2 Mounting on DIN rail

- **Mounting**



- ① Insert the bottom holder of amplifier unit to 35mm width DIN rail.
- ② Push the front part of the unit to arrow direction to mount.

- **Detaching**




- ① Connecting: Insert a connector of the sensor head into amplifier unit with aligning '↑' mark and '▲' mark until it sounds click.
- ② Disconnecting: Pull out the connector cap of sensor head to the opposite direction.

5.4 Check Point for Installing Sensor Head and Amplifier Unit


5.4.1 Ferrite core (accessory)

- **Sensor Head**




Within 30mm from the sensor head, wind the cable through the inside of the ferrite core three times and mount the ferrite core.

- **Extension cable (sold separately)**




Within 30mm from the connector of amplifier unit, wind the cable through the inside of the ferrite core three times and mount the ferrite core.

5.4.2 Connecting to amplifier unit



- ① **Connecting:** Insert connector of the sensor head into amplifier unit with aligning ↑ mark and ▲ mark until it sounds click.
 - ② **Disconnecting:** Pull out the connector cap of sensor head to the opposite direction.
- ※ Do not supply the power when connect / disconnect sensor head to amplifier unit.


5.4.3 Connecting amplifier units mutually



- ① Remove the side cover at the connecting side.
 - ② Connect the side connector to the units.
 - ③ After mounting amplifier unit on DIN rail, push it to arrow direction tightly.
- ※ In case of disconnecting, follow the upper sequence reversely.

5.4.4 Distinguishing master/slave amplifier units

When the power cable direction is down, the amplifier at the left end is the master unit, and the channel number of slaves increases sequentially to the right.




5.4.5 Precautions when connecting amplifier unit

- Mount on DIN rail.
- Do not supply the power when adding amplifier unit.
- Supply power to each connected amplifier unit at the same time.
- Up to 8 amplifier units can be connected, and only 1 calculation function can be performed per 1 group of mutually connected amplifiers.
- When the calculation function is activated, the setting values (SV) of the slave units are disable and the mutual interference prevention function for sensor heads is executed automatically.

5.5 Communication Converter


5.5.1 Mounting on DIN rail

- **Mounting**



- ① Insert bottom holder of communication converter to 35mm width DIN rail.
- ② Push the front part of the unit to arrow direction to mount.


- **Detaching**



- ① Side amplifier unit to ① direction.
- ② Pull the assembly part to ② direction to detach.

5.6 Check Point for Installing Communication Converter

5.6.1 Connecting to amplifier unit




- ① Remove the side cover at the connecting side.
 - ② Connect the side connector to the units.
 - ③ After mounting amplifier unit and communication unit on DIN rail, push it to arrow direction tightly.
- ※ In case of disconnecting, follow the upper sequence reversely.

5.6.2 Distinguishing master/slave amplifier units

When the power cable direction is down, the amplifier at the left end is the master unit, and the channel number of slaves increases sequentially to the right.

Communication converter is connected to the left side of master amplifier unit.



5.6.3 Precautions when connecting amplifier unit

- Mount on DIN rail.
- Do not supply the power when adding amplifier unit.
- Supply power to each connected amplifier unit at the same time.
- Up to 8 amplifier units can be connected, and only 1 calculation function can be performed per 1 group of mutually connected amplifiers.
- When the calculation function is activated, the setting values (SV) of the slave units are disable and the mutual interference prevention function for sensor heads is executed automatically.


6 Function – Amplifier Unit

6.1 Display When Power is ON

Displays control output setting screen when connecting a sensor head and supplying power at the first time, or replacing a sensor head. Set the output type as below sequence.


※ Refer to '6.2 Mode Setting' to check the setting range and the reset method.

- ① When 'OUT' is displayed on the present value (PV) display, select control output type through the [▲/▼] keys and push the [MODE] key.




- Setting value
 - NPN: NPN output (Default)
 - PNP: PNP output

- ② When 'R-OUT' is displayed on the present value (PV) display, select analog output type through the [▲/▼] keys and push the [MODE] key.



- Setting value
 - FFF: None (default) / 4-20mA: 4-20mA current output /
 - 0-5V: 0-5v voltage output / 1-5V: 1-5v voltage output / -5-5V: -5-5v voltage output

- ③ After 'OUT.SET' is flashed three times and it returns to the run mode.



6.2 Mode Setting

6.2.1 Parameter setting

| Mode | Key | Description |
|--|------------------------------|---|
| Run mode | | Present value (PV) display |
| | | <ul style="list-style-type: none"> • Solo: Displays present value (PV). • When using calculation: Displays the result of calculation, and calculation indicator (CALC) of master amplifier unit turns on. |
| | | Setting value(SV) display |
| | | Displays HIGH setting value, LOW setting value, real distance value (RV), analog output, bank |
| Sensing optimization | [AUTO] key over 2 sec | Optimizes the level of laser emission and receiving sensitivity regarding the object color and environment. |
| Zero adjustment | [ZERO] key over 2 sec | Sets the present value (PV) to the reference distance forcibly. |
| HIGH sensitivity adjustment | [MODE]+[▲] key over 2 sec | Sets the judgment output (HIGH/GO/LOW) range by manual input. |
| LOW sensitivity adjustment | [MODE]+[▼] key over 2 sec | |
| Auto sensitivity adjustment (Teaching) | [MODE] key within 2 sec | Sets the judgment output (HIGH/GO/LOW) range automatically. |
| | | <ul style="list-style-type: none"> • 1-point teaching Sets the judgment output range by using present value (PV) of reference object height. |
| | | <ul style="list-style-type: none"> • 2-point teaching Sets the judgment output range by using present value (PV) of reference object step. |
| Control output type | [MODE]+[AUTO] key over 2 sec | Sets the type of control/analog output. |
| HIGH PEAK value | [▲] key | Displays HIGH/LOW PEAK value. |
| LOW PEAK value | [▼] key | |
| Parameter group | [MODE] key over 2 sec | Enters to the parameter group 1 to 4. |

6.2.2 RUN mode setting

6.2.2.1 Present value (PV) display

- **Solo**

Displays present value (PV).

- **When using calculation**

Displays the result of calculation, and calculation indicator (CALC) of master amplifier unit turns on.

※ Refer to '7.4.1 Calculation [CALC]' for the details of calculation'.

6.2.2.2 Setting value(SV) display

- **Selection**

To change the type of value and turns on each recognition lamp, press [◀/▶] keys.

| Display | Description | Setting value (SV) indicator recognition lamp |
|---------------------|--|---|
| HIGH setting value | Displays high judgment value | Turns on 'HI' |
| LOW setting value | Displays low judgment value | Turns on 'LO' |
| Real distance value | Displays real distance value without zero adjustment, hold, and scale. | Turns on 'RV' |
| Analog output | Displays analog output value of voltage (V) or current (mA). | Turns on 'ANALOG' |
| Bank | Displays bank number | Turns off all recognition lamp |

6.2.2.3 HIGH/LOW PEAK display

- **Execution**

- Push [▲] key to display 'H-PEAK' on PV display and the value of high peak on SV display.
- Push [▼] key to display 'L-PEAK' on PV display and the value of low peak on SV display.

- **Setting**

- Push [▲] key over 3 sec during HIGH PEAK value display mode, initializes the value. If there is no present value, displays 'HHHH'.
- If push [▼] key over 3 sec during LOW PEAK value display mode, initializes the value. If there is no present value, displays 'LLLL'.

- **Exit**

If there is direction key input [◀] / [▶] / [▲] / [▼] or no key input for 5 sec, returns to run mode.

6.2.3 Sensing optimization

Optimizes the level of laser emission and receiving sensitivity regarding the object color and environment.

- **Execution**

Press [AUTO] key over 2 sec to execute the sensing optimization. When the optimization is finished, 'OK' is displayed on SV display and returns to run mode automatically.

6.2.4 Zero adjustment

Sets the present value (PV) to the reference distance forcibly.

After zero adjustment, displacement value is displayed on the basis of PV, not the reference distance.

- **Execution**

- Push [ZERO] key over 2 sec.
- Apply the signal to external input wire for zero adjustment over 3 sec.

- **Setting**

After 'ZERO' on PV display, '0000' is displayed, and PV is set as the reference distance.

- **Dismiss**

Initializes changed reference distance by zero adjustment.

- Push the [ZERO]+[MODE] keys over 2 sec.
- Apply the signal to external input wire of zero adjustment over 3 sec.




Note

If the present value is changed by zero adjustment, the setting values (HIGH SV, LOW SV etc.) are not changed.

6.2.5 Sensitivity adjustment

The device outputs judgment output by setting the range (HIGH/GO/LOW) and satisfying it. It is possible to set HIGH judgment value and LOW judgment value. HIGH judgment signal is outputted when PV is over HIGH judgment value and LOW judgment signal is outputted when PV is under LOW judgment value.

The range between HIGH judgment value and LOW judgment value is set as GO judgment range automatically and output GO judgment signal.



※ HIGH judgment value should be set greater than LOW judgment value. (HIGH judgment value > LOW judgment value)

6.2.5.1 Factory default

| Model | Setting range | Factory default | |
|--------|-------------------|--------------------|---------------------|
| | | LOW judgment value | HIGH judgment value |
| BD-030 | -99.999 to 99.999 | -5,000 | 5,000 |
| BD-065 | | -10,000 | 10,000 |
| BD-100 | | -20,000 | 20,000 |

※ Factory default is automatically set when connecting the sensor head to the amplifier unit.

6.2.5.2 Manual sensitivity adjustment

Sets the judgment output (HIGH/GO/LOW) range by manual input.

- **Execution**
 - Press [MODE] + [▲] over 2 sec to enter HIGH sensitivity adjustment.
 - Press [MODE] + [▼] over 2 sec to enter LOW sensitivity adjustment.
- **Setting**
 - Change the number of digit by the [◀] / [▶] keys.
 - Change the setting value by the [▲] / [▼] keys.
- **Exit**
 - Press [MODE] key within 2 sec to return to run mode.

6.2.5.3 Auto sensitivity adjustment (Teaching)

Set the judgment output (HIGH/GO/LOW) range automatically.

Enter the auto sensitivity adjustment setting mode after set the type of teaching mode in parameter 1 group.

※ Refer to '7.3.2 Teaching mode [SENS]' to check the selecting method of teaching type.

- **1-point teaching**

Sets the judgment output range by using present value (PV) of reference object height.

- HIGH setting value=height present value × 1.5

- LOW setting value=height present value ÷ 2

- **Execution**

Press key [MODE] key within 2 sec.

- **Setting**

① 'IP' is displayed on setting value (SV) display, push the [AUTO] key within 2 sec.

② After teaching the object for 2 sec, set the judgment output range automatically by applying the result.

- **2-point teaching**

Sets the judgment output range by using present value (PV) of reference object step.

- HIGH setting value=(step × 1.5)+bottom height

- LOW setting value=(step ÷ 2)+bottom height

- **Execution**

Press key [MODE] key within 2 sec.

- **Setting**
 - ① 'IP' is displayed on setting value (SV) display, push the [AUTO] key within 2 sec.
 - ② After teaching the object for 2 sec, '2P' is displayed on setting value (SV) display, push the [AUTO] key within 2 sec.
 - ③ After teaching the object for 2 sec, set the judgment output range automatically by applying the result.

6.2.6 Control output type

Sets the type of control/analog output.

Control output setting screen is displayed when connecting a sensor head and supplying power at the first time. It is possible to re-enter by below execution method.

※ Refer to '6.1 Display When Power is ON' to check about first power supply.

▪ Execution

Press [MODE] + [AUTO] keys over 2 sec.

▪ Setting

- ① 'OUT' is displayed on present value (PV) display, select the setting value by [▲] / [▼] key, and apply by [MODE] key.
 - Setting value
 - NPN: NPN output (Factory default)
 - PNP: PNP output
- ② 'R-OUT' is displayed on present value (PV) display, select analog output type, and apply by [MODE] key.
 - Setting value
 - OFF: Disable (Factory default) / 4-20mA: 4-20mA current output /
 - 0-5V: 0-5V voltage output / 1-5V: 1-5V voltage output /
 - 5-5V: -5-5V voltage output
- ③ After setting is finished, flashes 'OUT.SET' on present value(PV) display and 'END' on setting value (SV) display 3 times, and returns to run mode.

7 Parameter Group – Amplifier unit

7.1 Setting

- Push the [MODE] key over 2 sec to enter the parameter setting mode.
- In the setting mode, change the parameter group by the [◀/▶] keys and enter the group by pushing the [MODE] key.
- In the group, change the parameter by the [◀/▶] keys, select it by pushing the [MODE] key, and change the setting value by [▲/▼] keys
- In each step, push the [MODE] key over 3 sec to save and return to the upper step.

7.2 Configuration, Setting range and Factory default

This chapter is the guide with a brief description for parameter, setting range and factory default.

The amplifier unit automatically change the setting value by recognizing connected sensor head model.

※ Refer to the each chapter in '7 Parameter Group – Amplifier unit' for the details.

| PARAM | | Parameter group 1: Settings related to output type, displacement, display and error output. | | | |
|-------------|---------------|---|---------------------------------------|---------------------------------|-------------|
| Parameter | | Setting range | Description | Default | |
| <i>RSPd</i> | Response time | 330μs, 500μs, 1ms, 2ms, 5ms | Sets the data sampling response time. | 1ms | |
| <i>SENS</i> | Teaching mode | <i>IPNE</i> | 1-point | Sets the type of teaching mode. | <i>IPNE</i> |
| | | <i>2PNE</i> | 2-point | | |
| <i>NoNC</i> | Output type | <i>No</i> | Normally open | Sets the control output type. | <i>No</i> |
| | | <i>NC</i> | Normally closed | | |
| <i>diSP</i> | PV display | <i>StNd</i> | Standard | Sets the type of PV display. | <i>StNd</i> |
| | | <i>SCALE</i> | Scale | | |
| <i>dot</i> | Display digit | 0.000, 0.00, 0.0, 0 | Sets the decimal point of PV display. | 0.000 | |

| <i>PARA 1</i> Parameter group 1: Settings related to output type, displacement, display and error output. | | | | | |
|---|---------------------|----------------------------|-------------|---|---|
| Parameter | | Setting range | | Description | Default |
| <i>H-SC</i> | Display scale | -99.999 to 99.999 | | Sets the display scale value. | BD-030 <i>L-SC</i> : -5.000 <i>H-SC</i> : 5.000 |
| <i>L-SC</i> | | | | | BD-065 <i>L-SC</i> : -10.000 <i>H-SC</i> : 10.000 |
| <i>HYS</i> | Hysteresis | 0.001 to 99.999 | | Set the value of hysteresis. | 0.001 |
| <i>H-AN</i> | Analog output scale | -99.999 to 99.999 | | Changes present value (PV) to linear range (Scale) and output it as analog signal. | BD-030 <i>L-SC</i> : -5.000 <i>H-SC</i> : 5.000 |
| <i>L-AN</i> | | | | | BD-065 <i>L-SC</i> : -10.000 <i>H-SC</i> : 10.000 |
| <i>ERR.OUT</i> | Error output | <i>KEEP</i> | Keep PV | Select the type of output when an error occurs. ※ The default of fixed value is the maximum value of previously set analog output. | <i>KEEP</i> |
| | | <i>FIX</i> | Fixed value | | |
| <i>FIX.OUT</i> | Fixed output | Set value of analog output | | Outputs the fixed analog value when an error occurs. | Max. value within the range |

| PARAM2 | | Parameter group 2: Settings related to present value | | | |
|-----------|-----------------------|---|--------------------------|---|---------|
| Parameter | | Setting range | | Description | Default |
| CALC | Calculation | OFF | Off | Sets the type of inner-calculation. | OFF |
| | | ADD-AB | Add | | |
| | | SUB-AB | Subtraction | | |
| | | AVG | Average | | |
| GAIN | Gain | 1, 2, 3 | | Sets the level of sensing sensitivity which increases with level. | 1 |
| FILTER | Filter | AVF | Average | Sets the filter which controls deviation of present value (PV). | AVF |
| | | DIFF | Differential | | |
| AVF | Samples for averaging | 1, 2, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096 | | Sets the number of sampling for average. | 16 |
| MEDIAN | Samples for median | OFF, 3, 5, 7, 15, 31 | | Sets the number of sampling for median. | OFF |
| HOLD | Hold | OFF | Off | Set the output holding type for hold timing input [HOLD]. | OFF |
| | | PEAK | Peak | | |
| | | BOTTOM | Bottom | | |
| | | P-P | Difference | | |
| | | SAMPLE | Sample | | |
| | | AVG | Average | | |
| HOLDt | Hold timing input | EXTIN | External input | Set the sampling time condition for hold [HOLD]. ※ The parameter is activated when the value of hold [HOLD] is not OFF. | EXTIN |
| | | REUP | Over auto trigger level | | |
| | | REDW | Under auto trigger level | | |
| RELV | Auto trigger level | -99.999 to 99.999 | | Set the auto trigger level of hold timing input [HOLD]. ※ The parameter is activated when the value of hold timing input [HOLD] is over/under auto trigger level [REUP] or [REDW]. | 0 |

| PARAM2 Parameter group 2: Settings related to present value | | | | | |
|--|-------------------------|-----------------|-----------|--|------------|
| Parameter | | Setting range | | Description | Default |
| <i>RELHYS</i> | Auto trigger hysteresis | 0.001 to 99.999 | | Set the hysteresis value of Auto trigger level [<i>RELV</i>]. ※ The parameter is activated when the value of hold timing input [<i>ELN</i>] is over/under auto trigger level [<i>RELUP</i>] or [<i>RELW</i>]. | 0.001 |
| <i>ELMod</i> | Timer | <i>OFF</i> | Off | Sets the type of judgment output | <i>OFF</i> |
| | | <i>OND</i> | On delay | | |
| | | <i>OFD</i> | Off delay | | |
| <i>ELME</i> | Timer value | 0 to 9999 | | Set the delay or hold time of timer [<i>ELMod</i>]. | 0 |

| PARAM3 Parameter group 3: Settings related to external input. | | | | | |
|--|------------------|-------------------------------|--|---|---------------|
| Parameter | | Setting range | | Description | Default |
| <i>d-IN1</i> | External input 1 | <i>OFF</i> : Off | | Assigns the function to each external wire. | <i>ELN</i> |
| <i>d-IN2</i> | External input 2 | <i>ELN</i> : Timing input | | | <i>OUTCLR</i> |
| <i>d-IN3</i> | External input 3 | <i>OUTCLR</i> : Output reset | | | <i>L-OFF</i> |
| <i>d-IN4</i> | External input 4 | <i>L-OFF</i> : Stop emission | | | <i>ZERO</i> |
| | | <i>ZERO</i> : Zero adjustment | | | |
| | | <i>BANK-A</i> : Bank input-A | | | |
| | | <i>BANK-B</i> : Bank input-B | | | |

| PARAM4 Parameter group 4: Settings related to user convenience functions (This parameter group is common, not saved per bank separately) | | | | | |
|--|-------------------|--|-----------------|--|----------------|
| Parameter | | Setting range | | Description | Default |
| <i>DIR</i> | Display direction | Change display direction of present value (PV) and setting value (SV). | | | Normal display |
| <i>BANK</i> | Bank | <i>BANK-0</i> , <i>BANK-1</i> , <i>BANK-2</i> , <i>BANK-3</i> | | Save and load the parameter setting values. | <i>BANK-0</i> |
| <i>SAVE</i> | Saving mode | <i>OFF</i> | Off | If there is no user input over 1min in run mode, turn off the display to save power. | <i>OFF</i> |
| | | <i>SAVE1</i> | Digital display | | |
| | | <i>SAVE2</i> | All display | | |

| PARAM4 | | Parameter group 4: Settings related to user convenience functions (This parameter group is common, not saved per bank separately) | | | |
|-----------|------------|--|---|-------------|---------|
| Parameter | | Setting range | | Description | Default |
| LOCK | Lock mode | Set the type of key which lock function is applied. | | | OFF |
| | | OFF | Off | | |
| | | LOCK1 | [AUTO], [ZERO] key lock | | |
| | | LOCK2 | [AUTO], [ZERO] key + entering parameter group lock | | |
| | | LOCK3 | All key lock (except unlock key) | | |
| INIT | Initialize | OFF, CLR-b0, CLR-b1, CLR-b2, CLR-b3, CLR-A | CLR-b□: Initialize No. □ bank parameter setting value. CLR-A: Initialize all bank parameter setting value. | | OFF |

7.3 Parameter Group 1 [PARA 1]

Explains items within parameter group 1 related to output type, displacement, display and error output.

※ Refer to '7.2 Configuration, Setting range and Factory default' to check them of each item in group.

7.3.1 Response time [RESPd]

Sets the data sampling response time.

When measuring objects with extremely low reflectance, such as black rubber, the response time should be set as long enough to allow sufficient light to be received. Conversely, if fast sampling is required, set the response time as short.

| Frequency | Display | Brightness of object |
|-----------|---------|----------------------|
| 330μs | 3300US | Bright |
| | | |
| 5ms | 5MS | Dark |

7.3.2 Teaching mode [SENS]

Sets the type of teaching mode.

Auto sensitivity adjustment in '7.2 Configuration, Setting range and Factory default' is conducted by the mode selected in this parameter.

- **1-point teaching [1PNE]**

When the object is present, the value is measured and applied to calculate HIGH/LOW setting.

This is a useful function for determining the presence or absence of a detection object when there is a reference object.

- **2-point teaching [2PNE]**

The value is measured and applied separately when the object is present and not present.

This is a useful function for measuring the steps of object when there is a reference step.

※ Refer to '6.2.5 Sensitivity adjustment' to check the equation and setting details.

7.3.3 Output type [NoNC]

Selects output type (Normally open, Normally closed) for judgment output(HIGH/GO/LOW). Judgment signal with the type selected in this parameter is outputted according to the judgment output range which is set in ‘6.2.5 Sensitivity adjustment’.

7.3.4 PV display [di SP]

Sets the type of PV display.

- **Standard [SENd]**

Displays the measured value in rated measurement range per each sensor head.

- **Scale [SCALE]**

Displays the input within setting range of ‘High/Low display scale’.

※ Refer to ‘7.3.6 Display scale [H-SC / L-SC]’ in parameter group 1 to check the details of scale setting.

7.3.5 Display digit [dot]

Sets the decimal point of the present value (PV) and the setting value (SV).

- **Setting range**

| Range | Description |
|-------|---|
| 0.000 | Display 3 digit after the decimal point |
| 0.00 | Display 2 digit after the decimal point |
| 0.0 | Display 1 digit after the decimal point |
| 0 | Display integer |

7.3.6 Display scale [H-SC / L-SC]

※ Converts the present value (PV) to any linear range (scale) and displays it.

※ Only appears when ‘PV display [di SP]’ is set to ‘Scale [SCALE]’.

- **H-SC**

High display scale value for maximum input

- **L-SC**

Low display scale value for minimum input

※ The parameter is activated when the value of PV display [di SP] is ‘Scale [SCALE]’.



Ex.


▪ **Example setting table**

Based on sensor head BD-030 model

(Reference distance: 30mm, Maximum measurement range: 20 to 40mm, Rated display range: -5 to 5)

| Setting range | | Present value (PV) – Scale display (SD) | | | | | | | |
|---------------|------|---|-----|------|-----|-----|-----|-----|-----|
| H-SC | L-SC | PV1 | SD1 | PV2 | SD2 | PV3 | SD3 | PV4 | SD4 |
| -50 | 50 | -5 | -50 | -2.5 | -25 | 2.5 | 25 | 5 | 50 |
| 0 | 40 | -5 | 0 | -2.5 | 10 | 2.5 | 30 | 5 | 40 |
| 40 | 0 | -5 | 40 | -2.5 | 30 | 2.5 | 10 | 5 | 0 |


▪ **Example graph**



7.3.7 Hysteresis [HY5]

Sets specific value between ON/OFF of output and delay transition to prevent output instability due to chattering. Refer to below operation timing chart.

- **Hysteresis operation timing chart**



7.3.8 Analog output scale [H-AN / L-AN]

Converts present value (PV) into linear range (Scale) and output it to an analog signal.

- **H-AN**
High analog output scale value for maximum input
- **L-AN**
Low analog output scale value for minimum input
- ※ The parameter is activated when the value of analog output [A-OUT] is not OFF.



Ex.


- **Example setting table**

Based on sensor head BD-030 model, set analog output as ‘-5 to 5V’.

(Reference distance: 30mm, Maximum measurement range: 20 to 40mm, Rated display range: -5 to 5)

| Setting range | | Present value (PV) – Analog output (AO, -5 to 5V) | | | | | | | |
|---------------|------|---|-----|------|------|-----|-------|-----|-----|
| H-AN | L-AN | PV1 | AO1 | PV2 | AO2 | PV3 | AO3 | PV4 | AO4 |
| 5 | 0 | 5 | 5V | 3 | 1V | 2 | -1V | 0 | -5V |
| 0 | 5 | 0 | 5V | 2 | 1V | 3 | -1V | 5 | -5V |
| -5 | 5 | -5 | 5V | -2.5 | 2.5V | 2.5 | -2.5V | 5 | -5V |

- **Example graph**



7.3.9 Error output [ERR. OUT]

Select the type of output when an error (out of measurement range, lack or saturation of sensitivity), external input – output [OUT.ERR], filter delay (present value is lower than filter setting value) occurs.

※ Alarm output does not work during error output.

- **Keep PV [KEEP]**

Maintains and outputs the present value before an error occurs.

(Judgment output ON / Analog output ON)





- **Fixed value [FIX]**

Outputs the previously set value in '7.3.10 Fixed output [FIX. OUT]'.
(Judgment output OFF / Analog output ON)



Ex.

- Graph



7.3.10 Fixed output [FI %OUT]

Outputs the fixed analog value when an error occurs.

- ※ The parameter is activated when the value of analog output [A-OUT] is not OFF and error output [ERR-OUT] is Fixed value [FI %].

- Setting range and default by analog output

| Type | Analog output | Setting range | Default |
|---------|---------------|---------------|---------------|
| Current | 4-20mA | 4.00-20.00mA | Maximum value |
| Voltage | 0-5V | 0.000-5.000V | |
| | 1-5V | 1.000-5.000V | |
| | -5-5V | -5.000-5.000V | |

7.4 Parameter Group 2 [PARA2]

Explains items within parameter group 2 related to present value.

- ※ Refer to '7.2 Configuration, Setting range and Factory default' to check them of each item in group.

7.4.1 Calculation [CALC]

Inner-calculates the measurement value of multiple sensor head and output it.

When activating calculation, the mutual interference prevention function and the response speed setting change according to the number of connected amplifiers, and all setting is possible on the master amplifier unit.

- ※ Zero adjustment is possible in each device.
- ※ Only appears when multiple amplifier units are connected.

- **Off [OFF]**

Displays the measurement value separately per each sensor head. Set when communicating each amplifier unit and PC via communication converter.


- **Add [Add-Ab]**

Displays the added measurement value of 2 sensor heads.

Use when measuring a thickness of the object.

Place 2 sensor heads facing each other and adjust the object to be center of them.

- Equation: Sensor head A + Sensor head B




- **Subtraction [SUB-AB]**

Displays the difference between measurements of 2 sensor heads.

Use when measuring step, lifting, bending of the object.

- Equation: Sensor head A – Sensor head B




- **Average [AVG]**

Displays the average of measurements of 2 or more (up to 8) sensor heads.

Use when measuring a flatness of the object.

- Equation: (Sensor head A + Sensor head B + Sensor head C + ... + Sensor head N) ÷ N



7.4.2 Gain [GAIN]

When measuring target objects with low reflective light or large inclines in the measuring surface, adjust the level of the sensitivity of the sensor head to provide a stable instrument. The higher setting value makes sensitivity greater but it can be easily influenced by external factor and resolution might be lowered.



7.4.3 Filter [FILTER]

Sets the filter to adjust the deviation of the sensor head measurement value. BD series support 'Average [AVF]', 'Differential [DIFF]', 'Median [MEDIAN]' filters.

- ※ Median filter can be set through a separate parameter. Refer to '7.4.5 Samples for median [MEDIAN]'.
- ※ It is not possible to use 'Average [AVF]' and 'Differential [DIFF]' filters at the same time.



- **Average [AVF]**

Samples the most recent measurements and calculates the average and outputs them to reduce the rapid changes of the measured values.



- **Differential [DIFF]**

Outputs the difference between the current and the previous measurement. Use when detecting sharp deviations.



7.4.4 Samples for averaging [AVER]

Sets the number to sample for averaging. The amplifier unit calculates the average and outputs it.

※ Only appears when setting 'Filter [FILTER]' as 'Average [AVER]'.

7.4.5 Samples for median [MEDIAN]

Sets the number to sample for median. The amplifier unit calculates the median and outputs it. It is possible to filter out sudden changes in values (e.g., disturbance, noise, etc.) that cannot be removed by the average filters.

※ The median filter function is disabled by setting the parameter to OFF.

※ BD-series displacement sensor indicates the present value by processing the measurement in the order of the median → average / differential.

7.4.6 Hold [HOLD]

Maintains the display and outputs measurement value during the sampling time in the set type. The sampling time can be adjusted by setting the 'Hold Timing Input [HOLDT]' parameter.


※ Refer to '7.4.7 Hold timing input [HOLDT]' for the details of hold timing input.

※ 'Timer [T-MOD]' and 'Hold [HOLD]' cannot be used at the same time. When the timer function is enabled, the hold function setting automatically switches to OFF.

※ 'Filter [FILTER]' function may cause delays in operation.


▪ Peak [PEAK]

Outputs and maintains the maximum value during the sampling time. The output starts after the sampling ends and remains until the end of the next sampling.



- **Bottom [bottom]**


Outputs and maintains the minimum value during the sampling time. The output starts after the sampling ends and remains until the end of the next sampling.



- **Difference [P-P]**


Outputs and maintains the difference between maximum and minimum value during the sampling time. The output starts after the sampling ends and remains until the end of the next sampling.

※ Use when measuring vibration and eccentricity.




- **Sample [SAMPLE]**

Outputs and maintains the value of sampling start. The output starts after the sampling ends and remains until the end of the next sampling.



- **Average [AVG]**

Outputs and maintains the average value during the sampling time. The output starts after the sampling ends and remains until the end of the next sampling.



7.4.7 Hold timing input [HOLD dt]

Sets the input type of the sampling time for hold function.

- ※ Only appears when 'Hold [HOLD]' is not set to OFF.
- ※ When setting 'Over / Under auto trigger mode [A.L.U.P] / [A.L.d.W]', enters 'Auto trigger level [A.L.L.V]', 'Auto trigger level hysteresis [A.L.H.Y.S]' sequentially.


- **External input [E-IN]**

Inputs the trigger for sampling time by external input. Proceed sampling while external input signal is ON.




- **Over auto trigger level [A.L.U.P]**

Sets auto trigger level and starts the sampling when measuring the value greater than the auto trigger level. When measuring the value lower than the auto trigger level, exit the sampling.



- **Under auto trigger level [A.L.d.W]**

Sets auto trigger level and starts the sampling when measuring the value lower than the auto trigger level. When measuring the value greater than the auto trigger level, exit the sampling.



7.4.8 Auto trigger level [A.L.V.]

Sets the trigger level for auto trigger mode.

- ※ Only appears when setting ‘Hold timing input [HOLD]’ to ‘Over / Under auto trigger level [A.L.V.] / [A.L.W.]’.
- ※ When the ‘Display scale [H-SC] / [L-SC]’ function is applied, the trigger will operate based on the present value (PV).

7.4.9 Auto trigger hysteresis [A.HYS]

Sets the trigger hysteresis for the auto trigger mode of hold timing input.

- ※ Only appears when setting the ‘Hold timing input [HOLD]’ parameter to ‘Over / Under auto trigger level [A.L.V.] / [A.L.W.]’.


7.4.10 Timer [T-MODE]

Sets timing of judgement output (HI/GO/LOW).

- ※ ‘Timer [T-MODE]’ and ‘Hold [HOLD]’ functions can not be used at the same time. When activating ‘Timer [T-MODE]’, ‘Hold [HOLD]’ is set to OFF automatically.
- ※ After setting, ‘Timer value [T-ME]’ is set sequentially.


- **On delay [OND]**

Delays the output by the set time after the judgment.



- **Off delay [OFFd]**

Holds the judgment output for the set amount of time.



7.4.11 Timer value [tME]

Set the time to delay or hold the judgment output.

※ Only appears when setting 'Timer [tME]' to 'On delay [ONd]' or Off delay [OFFd]'.

7.5 Parameter Group 3 [PARA3]

Explains items within parameter group 2 related to external input.

- ※ Refer to ‘7.2 Configuration, Setting range and Factory default’ to check them of each item in group.

7.5.1 External input [d-IN]

Assigns the function to each external wire 1 to 4.


You can set each function individually or overlay it. Bank A and bank B functions cannot be overlaid.

- **Timing input [t-IN]**

Assigns hold trigger function for ‘Hold timing input [Hold t]’.

- ※ Refer to ‘7.4.7 Hold timing input [Hold t]’ for the details of ‘Hold timing input [Hold t]’.

- **Timing chart**




- Minimum input time: 4ms
- Delay time after sampling: 4ms

- **Output reset [OUT CLR]**

Assigns output reset function.

The output is stopped during the input. The input is terminated and the output resumes after 4ms.

- **Timing chart**




- Minimum input time: 4ms
- Output reset execution time: 8ms
- Reset release input time: 4ms

- **Stop emission [L - OFF]**

Assigns stop laser emission function.

After assigning, laser emission can be stopped by sending signal.

- **Timing chart**




- Minimum input time: 4ms
- Laser emission ON – OFF switch time: 12ms
- Laser emission OFF – ON switch time: 20ms

- **Zero adjustment [ZER0]**

Assigns zero adjustment function.

After assigning, present value (PV) can be set to zero point by sending signal.

- **Timing chart**



- Minimum input time: 4ms
- Execution time: Max. 1s
- Release input time: Min 3s

- **Bank input [bANK -A, bANK -b]**

Assigns bank load function.

After assigning, the bank is activated during the input.

- Use single wire

| Activation | BANK-A |
|------------|--------|
| BANK-0 | OFF |
| BANK-1 | ON |

- Use double wire

| Activation | BANK-A | BANK-B |
|------------|--------|--------|
| BANK-0 | OFF | OFF |
| BANK-1 | OFF | ON |
| BANK-2 | ON | OFF |
| BANK-3 | ON | ON |

※ Overlapping BANK-A, B is impossible.

7.6 Parameter Group 4 [PAR4]

Explains items within parameter group 2 related to user convenience.


- ※ Refer to '7.2 Configuration, Setting range and Factory default' to check them of each item in group.
- ※ Parameter group 4 is not saved per bank separately, but used in common.

7.6.1 Display direction [D/R]

Select display direction (normal, reverse) of amplifier unit to check conveniently regardless of the installation direction.

- ※ Reverse display changes the direction of number, not decimal point.

▪ Comparison of normal and reverse



7.6.2 Bank [BANK]

Parameter setting can be saved and loaded to 4 banks.

- **Check the bank number**

It is possible to check the bank number in use by pressing [◀] / [▶] key in the operation mode.

- **Save the bank**

After setting parameters, select the bank number in 'Parameter 4 group - Bank [BANK]' parameter. Press [MODE] key more than 3 seconds with the display flashing to save the parameters to the bank.

- **Load the bank**

Use the external output function, or select the bank number in 'Parameter 4 group - Bank [BANK]' parameter. Press [ZERO] key more than 3 seconds with the display flashing to load the parameters from the bank.

7.6.3 Saving mode [SAVE]

Reduces power consumption by extinguishing the front display lamp when there is no user input for a minute.

※ This function is only activated in run mode, all display are on in setting mode.


7.6.4 Lock mode [LOCK]

Set the key lock function to prevent operating errors.


※ Press [◀] / [▶] keys over 3 sec to lock or unlock the key in run mode.

- **Lock**

1st Press [◀] / [▶] keys over 3 sec in run mode.




2nd Lock mode is set with 'Lock mode parameter' and 'ON' as below.




- **Unlock**

1st Press [◀] / [▶] keys over 3 sec in run mode.



2nd Unlock mode is set with 'Lock mode parameter' and 'ON' as below.




7.6.5 Initialize [I N I E]


The bank and all settings can be initialized by selecting parameter.

- **Initialize**


1st Select 'Initialize [I N I E]' parameter. When pressing [MODE] key, 'OFF' is flashed in SV display.




2nd Select the bank to initialize by pressing [▲] / [▼] keys.



3rd After selecting the bank to initialize and pressing [MODE] key, 'NO' is flashed on SV display.



4th Select 'YES' by pressing [▲] / [▼] keys and press [MODE] key. All display are flashed and initialize is complete.



8 Error – Amplifier unit

In error status, 'ERROR' is displayed on present value (PV) display.


Deal with an error by referring to the below solution of each setting value (SV) display.

| Setting value (SV) display | Output | Reason | Solution |
|----------------------------|--------|--|--|
| HEAD | 0 | Disconnection of sensor head/amplifier unit/cable Sensor head malfunction | Check the connection between sensor head and amplifier unit. Check the disconnection of sensor head cable. Perform the above items and supply the power again. If the problem is not resolved after the above items are performed, it is judged that the sensor head is defective and needs to be replaced. |
| LASER | 0 | Malfunction of emission | |
| DARK | - | Not existing the object or background in maximum measurement range | Adjust the distance between sensor head and object in the maximum measurement range. |
| RANGE | - | | |
| BRIGHT | - | Over receive the light | |
| ----- | - | In status of display unavailable | Return to status of present value display available. |
| A-MEM | 0 | Amplifier unit memory malfunction (EEPROM cannot be refreshed due to exceeding the number of recording over 1 million times) | Turn off the power, check the connection of sensor head, and supply the power again. Executes the initialize 'INIT' function. If the problem is not resolved after the above items are performed, it is judged that the amplifier unit is defective and needs to be replaced. |
| H-MEM | 0 | Sensor head memory malfunction | Turn off the power, check the connection of sensor head, and supply the power again. If the problem is not resolved after the above item is performed, it is judged that the amplifier unit is defective and needs to be replaced. |

| Setting value (SV) display | Output | Reason | Solution |
|----------------------------|--------|--|--|
| <i>AMP-C</i> | 0 | Poor connection between amplifier units. | Check the connection between amplifier units, and supply the power again. |
| <i>VER</i> | 0 | Mismatch the version of firmware between sensor head and amplifier unit. | Please contact the Autonics technical advisory center. |
| <i>OUT</i> | 0 | Disconnection of the judgement output | After turn off the power, check connection of HIGH (black) / GO (gray) / LOW (orange) wire, and supply the power again. |
| <i>AUTO</i> | - | Teaching failure | After check the object is in the maximum measurement range, execute again. |
| <i>AMP</i> | 0 | Amplifier unit error | After turn off the power, check the connection of sensor head, and supply the power again. If the problem is not resolved after the above items are performed, it is judged that the amplifier unit is defective and needs to be replaced. |
| <i>OCUR</i> | 0 | Over current of output terminal | Check the load of output is specification range. Check the output is contacted other wire or frame. |

9 Communication Converter

9.1 Communication Setting Switch



Default: All switches are OFF

Communication speed (Switch 1, 2): Sets RS-232C, RS-485 communication speed to external device.

| Communication Speed | Switch 1 | Switch 2 |
|---------------------|----------|----------|
| 9600bps | ON | ON |
| 19200bps | OFF | ON |
| 38400bps | ON | OFF |
| 115200bps | OFF | OFF |


Address (Switch 3 to 7): Sets the address of communication converter. It is calculated in binary according to the ON/OFF status of each switch.

| Switch No. | Switch 3 | Switch 4 | Switch 5 | Switch 6 | Switch 7 | Address |
|-------------------------------|----------|----------|----------|----------|----------|---|
| Binary digit OFF=0 ON=1 | 2^4 | 2^3 | 2^2 | 2^1 | 2^0 | Address= $\text{Switch3} \times 2^4 + \text{Switch4} \times 2^3 +$ $\text{Switch5} \times 2^2 + \text{Switch6} \times 2^1 +$ $\text{Switch7} \times 2^0 + 1$ |
| Address 1 | OFF | OFF | OFF | OFF | OFF | $1 = 0 \times 2^4 + 0 \times 2^3 + 0 \times 2^2 + 0 \times 2^1 + 0 \times 2^0 + 1$ |
| Address 2 | OFF | OFF | OFF | OFF | ON | $2 = 0 \times 2^4 + 0 \times 2^3 + 0 \times 2^2 + 0 \times 2^1 + 1 \times 2^0 + 1$ |
| Address 3 | OFF | OFF | OFF | ON | ON | $3 = 0 \times 2^4 + 0 \times 2^3 + 0 \times 2^2 + 1 \times 2^1 + 1 \times 2^0 + 1$ |
| ... | ... | ... | ... | ... | ... | ... |
| Address 16 | ON | OFF | ON | ON | ON | $16 = 1 \times 2^4 + 0 \times 2^3 + 1 \times 2^2 + 1 \times 2^1 + 1 \times 2^0 + 1$ |
| ... | ... | ... | ... | ... | ... | ... |
| Address 31 | ON | ON | ON | ON | OFF | $31 = 1 \times 2^4 + 1 \times 2^3 + 1 \times 2^2 + 1 \times 2^1 + 0 \times 2^0 + 1$ |
| Address 32 | ON | ON | ON | ON | ON | $32 = 1 \times 2^4 + 1 \times 2^3 + 1 \times 2^2 + 1 \times 2^1 + 1 \times 2^0 + 1$ |

| Parity bit (switch 8, 9): Sets parity bit for RS-232C, RS-485 communication. | | |
|---|-----------------|-----------------|
| Parity | Switch 8 | Switch 9 |
| Even | ON | ON |
| Odd | OFF | ON |
| None | ON | OFF |
| None | OFF | OFF |

| Stop bit (switch 10): Sets stop bit for RS-232C, RS-485 communication. | |
|---|------------------|
| Stop bit | Switch 10 |
| 2bit | ON |
| 1bit | OFF |

9.2 Status Indicator – Communication converter



| Power indicator (POWER): Green, Displays power supply. | | |
|---|-----------------------|---|
| Status | Reason | Solution |
| On | Power is supplied | - |
| Off | Power is not supplied | After checking the connection between communication converter and amplifier unit correctly, reconnect the device. |

| Communication output indicator (TX): Green, Displays communication output status from communication converter to external device. | | |
|--|--------------------------|----------|
| Status | Reason | Solution |
| Flashing | Signal is outputting | - |
| Off | Signal is not outputting | - |

| Communication input indicator (RX): Green, Displays communication input status from communication converter to external device. | | |
|--|-------------------------|----------|
| Status | Reason | Solution |
| Flashing | Signal is inputting | - |
| Off | Signal is not inputting | - |

| Communication error indicator (ERROR): Red, Displays the communication status of communication converter. | | |
|--|--|---|
| Status | Reason | Solution |
| On | Connection is bad between communication converter and amplifier unit. | After checking the connection between communication converter and amplifier unit correctly, reconnect the device. |
| Flashing | Communication is bad between communication converter and amplifier unit. | After checking the connection between communication converter and amplifier unit correctly, reconnect the device. |
| | | Apply noise prevention to communication converter and amplifier unit. |
| Off | Operation is normal. | - |

9.3 Dedicated Device Management Program (atDisplacement)

atDisplacement is a comprehensive management program that can be used with Autonics BD-C Series.

atDisplacement provides GUI control for easy and convenient parameter setting and monitoring data management of multiple devices.



Features

- Checking product information
 - It is possible to check information about connected products by status window.
BD-C series Communication Converter: model, firmware version
BD series amplifier unit: each channel model, hardware version, firmware version, connected head unit model, status of connection
 - Monitoring
 - Live data
Displays the state and the present value (PV) of amplifier unit numerically.
 - Live Graph
Displays the present value (PV) graph of the connected amplifier unit in real time.
 - Waveform Graph
Displays the waveform graph of the connected amplifier unit in real time.
 - Setting
 - Parameter setting
Checks and changes the setting value of the connected amplifier units.
 - Bank management
Manages parameter bank of connected amplifier units by save and load.
- ※ For more information, visit our website (www.autonics.com) to download 'atDisplacement user manual'.

Make Life Easy: Autonics