

Autonics Diffuse reflective type Mapping Sensor [CC-LINK] BWML Series

INSTRUCTION MANUAL



Thank you for choosing our Autonics product. Please read the following safety considerations before use.

■ Safety Considerations

※Please observe all safety considerations for safe and proper product operation to avoid hazards.

- Warning Failure to follow these instructions may result in serious injury or death.
Caution Failure to follow these instructions may result in personal injury or product damage.


Warning

- 1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.
2. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
3. Do not connect, repair, or inspect the unit while connected to a power source.
4. Check the color of cables before wiring.
5. Do not disassemble or modify the unit.
6. This product is not safety sensor and does not observe any domestic nor international safety standard.

Caution


- 1. Use the unit within the rated specifications.
2. Use dry cloth to clean the unit, and do not use water or organic solvent.
3. Do not use a load over the range of rated relay specification.

■ Ordering Information



※: This information is intended for product management of custom order option. (no need to refer when selecting model)

■ Structure




- ① USB port: This port is only for firmware upgrade, channel setting, and A/S.
② Comm. status indicator: It displays the communication status through LED.
③ Power cable connector
④ Comm. speed setting switch (B RATE): You can set CC-LINK communication speed.
⑤ Comm. address setting switch: You can set CC-LINK address. (X10: 10^1, X1: 10^0)
⑥ CC-LINK comm. connector

■ Function

Background sensing mode: This function instructs adjusting angle to install the product by displaying presence of the background object in the status display when installing the product.

Installation guide mode: This function displays whether the sensing target is in the stable position of the guide line when installing the product through the output indicator.

Sensing level setting: This function sets sensitivity by dividing receiving light into 5 levels for stable sensing.



Output option: After setting output option, press key to set additional option.

Table with 4 columns: Output option (status display), Description, Additional option, Output option (status display), Description, Additional option.

Self-diagnosis: This function runs self-diagnose periodically in normal operation and displays the part in error at the status display when error occurs.

- Channel interference alarm: Outputs alarm when interference from another sensing target and external object in a channel area.
Disturbing light sensing alarm: Outputs alarm when the receiver received external light besides light from the emitter.
Emitter/Receiver damage alarm: Outputs alarm when emitter/receiver is damaged due to the long-term usage of emitter/receiver elements or strong impact to the product.


The above specifications are subject to change and some models may be discontinued without notice. Be sure to follow cautions written in the instruction manual and the technical descriptions (catalog, homepage).

■ Specifications


Specifications table with columns for Model, Sensing type, Sensing distance, Sensing target, Sensing area, Sensing target pitch, Sensing CH, CH ordering orientation, Beam pattern, Power supply, Protection circuit, Current consumption, Operation mode, Response time, Control output, Noise immunity, Dielectric strength, Insulation resistance, Vibration, Shock, Environment, Material, Accessory, Protection structure, Approval, Weight.

- ※1: This product is order made.
※2: The number of connectable units = 16 × A + 54 × B + 88 × C ≤ 2304
※3: The weight includes packaging. The weight in parenthesis in for unit only.
※Environment resistance is rated at no freezing or condensation.

■ Dimensions



※Max. sensing area = 20 × (sensing target pitch × (the total number of sensing target-1))




■ Output Connector

Table with columns: Connector socket, Specifications, Manufacture. Lists connector socket options and their specifications.


■ Installation and Adjustment

- ① Install the product on the right side of the sensing target with the bracket.
② Adjust the height of the product to the place where the first glass of the full cassette is aligned with the installation guide line.




- ③ Supply the power.
④ Enter to the background sensing mode to detect background.
⑤ Finish installation, when all channels are turned on after placing full cassette.
⑥ If all channels are not turned on, enter to the installation guide mode and adjust the product up and down.
※If there is disturbing light (fluorescent light) near the product, install the product vertically away from the disturbing light (fluorescent light).
※Use the product only for sensing the glass over the 6.5 generation.

■ Mode Switching Method



- ※1: When the status display is 0, press key to return to the run mode.
※2: Entering to the installation guide mode and pressing key starts teaching, and the product returns to the run mode after teaching completed.

■ Operation Timing Diagram



※The waveforms of 'Operation indicator' and 'CC-LINK output' are for Light ON. The waveforms are reversed for Dark ON.

■ CC-LINK Baud Rate and Address Setting

- For CC-LINK setting, communication speed of PLC Master and BWML should be the same.
Address is available from 1 to 64 and it should not be duplicated.
When changing CC-LINK setting, turn OFF the power of this unit and re-supply the power.

Table with columns: Setting, Setting range. Lists Baud rate and Address of unit settings.

■ Operation Indicator

Table with columns: Item, Output indicator (red LED), Stability indicator (green LED). Lists indicators for light ON/OFF and flashing.

● Status indicator

Table with columns: Item, Output indicator, Stability indicator, Status (Green, Yellow, Red), Status display, Communication output. Lists various status indicators and their meanings.

※1: If emitter and receiver are damaged at the same time, output of receiver is prior to that of emitter, and lower number of channel indicator is turned on.
※N stands for all channel.

● Communication status indicator

Table with columns: CC-LINK, STATE, RD/SD, Comm. status indicator. Lists communication status indicators.

■ Troubleshooting

Table with columns: Malfunction, Cause, Troubleshooting. Lists common malfunctions and their solutions.

■ Cautions during Use

- 1. Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
2. 24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
3. Use the product, 1 sec after supplying power.
4. When using switching mode power supply to supply the power, ground F.G. terminal and connect a condenser between 0V and F.G. terminal to remove noise.
5. When connecting a DC relay or other inductive load, remove surge by using diodes or varistors.
6. Wire as short as possible and keep away from high voltage lines or power lines, to prevent surge and inductive noise.
7. This unit may be used in the following environments.